

PD HS Midwest Quiet Air - L Instructions for Installation
 Turbine Assembly P/N 23065

v02



1 Place black o-ring into back cap



2 Place blue o-ring onto front bearing of turbine assembly



3 Insert TA into back cap



4 Place washer, then plate onto TA



5 Insert and screw on TA and back cap, refer to section 5 of TA Installation Procedure

