



1 Place o-ring into back cap



2 Place o-ring into head housing using insertion tool



3 Insert turbine assembly into head housing



4 Screw on back cap, refer to section 5 of the TA Installation Procedure

