



1 Place 3-point washer and o-ring into back cap



2 Place 3-point washer, plastic washer, o-ring in head housing



3 Insert turbine assembly into head housing



4 Screw on back cap, refer to section 5 of the TA Installation Procedure

